Instructions for any minor patching repairs

Included with your shipment is a Thick-mix kit (patch kit)
To be used for any minor patches or surface repairs which
might be needed during the installation process.

This kit includes:

- I. Thick-mix (patching compound) which matches the Gel-Coat color
- 2. Catalyst or MEKP (hardener for Thick-mix)
- 3. Measuring cups for Catalyst
- 4. Mixing cups
- 5. Tongue depressors for mixing

Steps for using Thick-mix

- 1. Mix a maximum of 10 ml. of Catalyst (MEKP) to each pint of Thick-mix.
- 2. You can adjust the ratio of Catalyst to accommodate smaller or larger amounts of Thick-mix as needed.
- 3. You will have a mix to use time of approximately 15 minutes at moderate temperatures.
- 4. Be sure not to use more than the recommended amount of Catalyst, as this product is extremely flammable. If smoke starts to appear from mixture, this means it has been mixed too hot and simply extinguish with water.
- 5. Lightly sand chipped or damaged area to be filled to provide the Thick-mix an area to bond to.
- 6. Use provided tongue-depressor to fill the area to be repaired and smooth with a flexible straight edge.

IMPORTANT

DO NOT USE THICK-MIX TO FILL IN ANY SEAMS